


External Pot for controlling the intensity of Light.



Male Connector – Connect directly to Light

Female Connector – To Power Supply Cable

Pot is used with the Smart Vision Light and standard power cable. IVP-C1 is to be connected between the light and the power cable for light.